

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710

FTS511 CHEVY C1500 BALL JOINT
SPACERS

INCL: 2 SPACERS, 8 BLTS, 8 NUTS, 8
WASHERS

Disconnect the negative terminal on the battery.
THE BALL JOINT SPACER IS TO BE
INSTALLED BETWEEN THE UPPER
CONTROL ARM (UCA) & THE UPPER BALL
JOINT (UBJ). AFTER REMOVING THE
RIVETS SECURING THE UBJ TO THE UCA,
REAM THE HOLES IN THE UCA & UBJ TO
3/8". PLACE THE UBJ BELOW THE UCA,
WITH THE SPACER SEPARATING THE
BOTTOM SURFACE OF THE UCA FROM
THE TOP SURFACE OF THE UBJ. INSERT
THE BOLTS FROM THE BOTTOM UP WITH
THE NUTS & WASHERS ON TOP OF THE
UCA. TORQUE TO 30 FT/LBS.

FOR TECHNICAL ASSISTANCE CALL:
877-4-FABTECH

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710

FTS511 CHEVY C1500 BALL JOINT
SPACERS

INCL: 2 SPACERS, 8 BLTS, 8 NUTS, 8
WASHERS

Disconnect the negative terminal on the battery.
THE BALL JOINT SPACER IS TO BE
INSTALLED BETWEEN THE UPPER
CONTROL ARM (UCA) & THE UPPER BALL
JOINT (UBJ). AFTER REMOVING THE
RIVETS SECURING THE UBJ TO THE UCA,
REAM THE HOLES IN THE UCA & UBJ TO
3/8". PLACE THE UBJ BELOW THE UCA,
WITH THE SPACER SEPARATING THE
BOTTOM SURFACE OF THE UCA FROM
THE TOP SURFACE OF THE UBJ. INSERT
THE BOLTS FROM THE BOTTOM UP WITH
THE NUTS & WASHERS ON TOP OF THE
UCA. TORQUE TO 30 FT/LBS.

FOR TECHNICAL ASSISTANCE CALL:
877-4-FABTECH

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710

FTS511 CHEVY C1500 BALL JOINT
SPACERS

INCL: 2 SPACERS, 8 BLTS, 8 NUTS, 8
WASHERS

Disconnect the negative terminal on the battery.
THE BALL JOINT SPACER IS TO BE
INSTALLED BETWEEN THE UPPER
CONTROL ARM (UCA) & THE UPPER BALL
JOINT (UBJ). AFTER REMOVING THE
RIVETS SECURING THE UBJ TO THE UCA,
REAM THE HOLES IN THE UCA & UBJ TO
3/8". PLACE THE UBJ BELOW THE UCA,
WITH THE SPACER SEPARATING THE
BOTTOM SURFACE OF THE UCA FROM
THE TOP SURFACE OF THE UBJ. INSERT
THE BOLTS FROM THE BOTTOM UP WITH
THE NUTS & WASHERS ON TOP OF THE
UCA. TORQUE TO 30 FT/LBS.

FOR TECHNICAL ASSISTANCE CALL:
877-4-FABTECH

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710

FTS511 CHEVY C1500 BALL JOINT
SPACERS

INCL: 2 SPACERS, 8 BLTS, 8 NUTS, 8
WASHERS

Disconnect the negative terminal on the battery.
THE BALL JOINT SPACER IS TO BE
INSTALLED BETWEEN THE UPPER
CONTROL ARM (UCA) & THE UPPER BALL
JOINT (UBJ). AFTER REMOVING THE
RIVETS SECURING THE UBJ TO THE UCA,
REAM THE HOLES IN THE UCA & UBJ TO
3/8". PLACE THE UBJ BELOW THE UCA,
WITH THE SPACER SEPARATING THE
BOTTOM SURFACE OF THE UCA FROM
THE TOP SURFACE OF THE UBJ. INSERT
THE BOLTS FROM THE BOTTOM UP WITH
THE NUTS & WASHERS ON TOP OF THE
UCA. TORQUE TO 30 FT/LBS.

FOR TECHNICAL ASSISTANCE CALL:
877-4-FABTECH