

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710

FTS512 CHEVY C3500 BALL JOINT SPACERS
INCL: 2 SPACERS, 8 BLTS, 8 NUTS, 8 WASHERS
Disconnect the negative terminal on the battery.
THE BALL JOINT SPACER IS TO BE INSTALLED
BETWEEN THE UPPER CONTROL ARM (UCA) &
THE UPPER BALL JOINT (UBJ). AFTER
REMOVING THE RIVETS SECURING THE UBJ TO
TO THE UCA, REAM THE HOLES IN THE UCA &
UBJ TO 3/8". PLACE THE UBJ BELOW THE UCA,
WITH THE SPACER SEPARATING THE BOTTOM
SURFACE OF THE UCA FROM THE TOP
SURFACE OF THE UBJ. INSERT THE BOLTS
FROM THE BOTTOM UP WITH THE NUTS &
WASHERS ON TOP OF THE UCA.

FOR TECHNICAL ASSISTANCE CALL:

877-4-FABTECH

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710

FTS512 CHEVY C3500 BALL JOINT SPACERS
INCL: 2 SPACERS, 8 BLTS, 8 NUTS, 8 WASHERS
Disconnect the negative terminal on the battery.
THE BALL JOINT SPACER IS TO BE INSTALLED
BETWEEN THE UPPER CONTROL ARM (UCA) &
THE UPPER BALL JOINT (UBJ). AFTER
REMOVING THE RIVETS SECURING THE UBJ
TO THE UCA, REAM THE HOLES IN THE UCA &
UBJ TO 3/8". PLACE THE UBJ BELOW THE UCA,
WITH THE SPACER SEPARATING THE BOTTOM
SURFACE OF THE UCA FROM THE TOP
SURFACE OF THE UBJ. INSERT THE BOLTS
FROM THE BOTTOM UP WITH THE NUTS &
WASHERS ON TOP OF THE UCA.

FOR TECHNICAL ASSISTANCE CALL:

877-4-FABTECH

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710

FTS512 CHEVY C3500 BALL JOINT SPACERS
INCL: 2 SPACERS, 8 BLTS, 8 NUTS, 8 WASHERS
Disconnect the negative terminal on the battery.
THE BALL JOINT SPACER IS TO BE INSTALLED
BETWEEN THE UPPER CONTROL ARM (UCA) &
THE UPPER BALL JOINT (UBJ). AFTER
REMOVING THE RIVETS SECURING THE UBJ TO
TO THE UCA, REAM THE HOLES IN THE UCA &
UBJ TO 3/8". PLACE THE UBJ BELOW THE UCA,
WITH THE SPACER SEPARATING THE BOTTOM
SURFACE OF THE UCA FROM THE TOP
SURFACE OF THE UBJ. INSERT THE BOLTS
FROM THE BOTTOM UP WITH THE NUTS &
WASHERS ON TOP OF THE UCA.

FOR TECHNICAL ASSISTANCE CALL:

877-4-FABTECH

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710

FTS512 CHEVY C3500 BALL JOINT SPACERS
INCL: 2 SPACERS, 8 BLTS, 8 NUTS, 8 WASHERS
Disconnect the negative terminal on the battery.
THE BALL JOINT SPACER IS TO BE INSTALLED
BETWEEN THE UPPER CONTROL ARM (UCA) &
THE UPPER BALL JOINT (UBJ). AFTER
REMOVING THE RIVETS SECURING THE UBJ
TO THE UCA, REAM THE HOLES IN THE UCA &
UBJ TO 3/8". PLACE THE UBJ BELOW THE UCA,
WITH THE SPACER SEPARATING THE BOTTOM
SURFACE OF THE UCA FROM THE TOP
SURFACE OF THE UBJ. INSERT THE BOLTS
FROM THE BOTTOM UP WITH THE NUTS &
WASHERS ON TOP OF THE UCA.

FOR TECHNICAL ASSISTANCE CALL:

877-4-FABTECH