

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710
909-597-7800

FTS710 NISSAN BALL JOINT SPACERS
INCL: 2 SPACERS, 8 BLTS, 8 WASHERS,
8 LOCK WASHERS

THE BALL JOINT SPACER IS TO BE
INSTALLED BETWEEN THE UPPER CONTROL
ARM (UCA) & THE UPPER BALL JOINT (UBJ).
AFTER REMOVING THE BOLTS SECURING
THE UBJ TO THE UCA, PLACE THE SPACER IN
BETWEEN THE UBJ AND THE UCA. SLIDE A
LOCK WASHER FOLLOWED BY A FLAT
WASHER ONTO EACH BOLT AND APPLY A
SMALL AMOUNT OF THREAD LOCKING
COMPOUND TO THE THREADS. INSERT THE
BOLTS THROUGH THE UCA AND HAND
TIGHTEN. AFTER ALL BOLTS ARE IN
POSITION, FULLY TORQUE ALL FOUR BOLTS.

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710
909-597-7800

FTS710 NISSAN BALL JOINT SPACERS
INCL: 2 SPACERS, 8 BLTS, 8 WASHERS,
8 LOCK WASHERS

THE BALL JOINT SPACER IS TO BE
INSTALLED BETWEEN THE UPPER CONTROL
ARM (UCA) & THE UPPER BALL JOINT (UBJ).
AFTER REMOVING THE BOLTS SECURING
THE UBJ TO THE UCA, PLACE THE SPACER IN
BETWEEN THE UBJ AND THE UCA. SLIDE A
LOCK WASHER FOLLOWED BY A FLAT
WASHER ONTO EACH BOLT AND APPLY A
SMALL AMOUNT OF THREAD LOCKING
COMPOUND TO THE THREADS. INSERT THE
BOLTS THROUGH THE UCA AND HAND
TIGHTEN. AFTER ALL BOLTS ARE IN
POSITION, FULLY TORQUE ALL FOUR BOLTS.

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710
909-597-7800

FTS710 NISSAN BALL JOINT SPACERS
INCL: 2 SPACERS, 8 BLTS, 8 WASHERS,
8 LOCK WASHERS

THE BALL JOINT SPACER IS TO BE
INSTALLED BETWEEN THE UPPER CONTROL
ARM (UCA) & THE UPPER BALL JOINT (UBJ).
AFTER REMOVING THE BOLTS SECURING
THE UBJ TO THE UCA, PLACE THE SPACER IN
BETWEEN THE UBJ AND THE UCA. SLIDE A
LOCK WASHER FOLLOWED BY A FLAT
WASHER ONTO EACH BOLT AND APPLY A
SMALL AMOUNT OF THREAD LOCKING
COMPOUND TO THE THREADS. INSERT THE
BOLTS THROUGH THE UCA AND HAND
TIGHTEN. AFTER ALL BOLTS ARE IN
POSITION, FULLY TORQUE ALL FOUR BOLTS.

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710
909-597-7800

FTS710 NISSAN BALL JOINT SPACERS
INCL: 2 SPACERS, 8 BLTS, 8 WASHERS,
8 LOCK WASHERS

THE BALL JOINT SPACER IS TO BE
INSTALLED BETWEEN THE UPPER CONTROL
ARM (UCA) & THE UPPER BALL JOINT (UBJ).
AFTER REMOVING THE BOLTS SECURING
THE UBJ TO THE UCA, PLACE THE SPACER IN
BETWEEN THE UBJ AND THE UCA. SLIDE A
LOCK WASHER FOLLOWED BY A FLAT
WASHER ONTO EACH BOLT AND APPLY A
SMALL AMOUNT OF THREAD LOCKING
COMPOUND TO THE THREADS. INSERT THE
BOLTS THROUGH THE UCA AND HAND
TIGHTEN. AFTER ALL BOLTS ARE IN
POSITION, FULLY TORQUE ALL FOUR BOLTS.